




Bild Nr. Picture No.	Ersatzteil-Nr. Spare Part No.	Bezeichnung	Description	Désignation
Art. 9881		Grasschere AccuCut Li	Grass Shear AccuCut Li	Cisaille à gazon AccuCut Li
2	9850-00.610.00	Steckerladegerät EU/DE	Battery charger EU/DE	Transformateur de charge EU/DE
3	9850-00.620.00	Messersatz, vollst.	Blade set, cpl.	Jeu de lames, cpl.
4	9850-00.620.05	Messerschutz	Blade protection	Protection de lame
5	9850-00.600.17	Kufe	Runner	Patin
Art. 9883		Set Accu Cut Li Gras- und Strauchschere	Set AccuCut Li Grass and Shrubshear	Kit Cisaille à gazon Accu Cut Li + lame taille-buissons
2	9850-00.610.00	Steckerladegerät EU/DE	Battery charger EU/DE	Transformateur de charge EU/DE
3	9851-00.620.00	Messersatz, vollst.	Blade set, cpl.	Jeu de lames, cpl.
4	9851-00.620.06	Messerschutz	Blade protection	Protection de lame
5	9850-00.600.17	Kufe	Runner	Patin
		Nur die aufgeführten Teile sind lieferbar!	Only the mentioned spare parts are available!	Seules les pièces indiquées sont disponibles!